Technology Selection RFID

LF/HF/UHF










Quick Physics Lesson (Reminder)



- Radio signals are electromagnetic waves, having a magnetic component (H-Field) and an electric component (E-Field)
- LF & HF systems use the Magnetic field only to transfer power and information by induction and coil antennas
 - Strength of this field falls off quickly
 - Liquids have less of an effect on H-Field
 - UHF systems use the Electromagnetic field to transfer power and information by capacitive coupling with dipole antennas
 - Strength of this field doesn't fall off as quickly which provides for a potentially longer read distances
 - Liquids absorb this field and reduce performance
 - Metals either shield signals or detune the tags
 - Special metal mount tags are typically required










Frequency of Operation

RFID tags exhibit different characteristics at different frequencies:

RADIO FREQUENCY SPECTRUM











Low Frequency < 135 kHz

ADVANTAGES

DISADVANTAGES

Relative freedom from regulatory limitations

Best performance because of the high max. regulatory field strength level (1.3m, button tag)

Freedom to design different tag antenna form factors (compared to HF and UHF) gives best performance with small tag designs

Penetrates materials well e.g. water, tissue, wood, body

Excellent non-line-of-sight communications

Very well defined read zone

No limitation using ferrite antenna for improved performance

Does not penetrate or transmit around metals e.g. iron, steel

Slow read speeds: Can only read ~ 20 tags per second (4k Bit/second)
Relatively large reader antennae

Inlay construction

- Is thicker than 13.56MHz and 900MHz
- Inlay may be more expensive i.e. application dependent
- Requires wire antenna, typically > 100 turns

Simple and low cost readers and <u>ante</u>nnae









High Frequency 13.56 MHz

ADVANTAGES DISAD

Simpler antenna design and lower manufacturing cost for paper label inlay (typical design: IC glued to etched antenna on plastic foil)

Does not penetrate or transmit around metals

Higher data rates: Can read up to 50 tags/second

Medium read range (50cm, button tag)

Good non-line-of-sight communication

For same read range compared to LF, bigger tag size is required

Controlled read zone

Constraints in designing different antenna form factors for readers and tags (low performance for small sized antennae)

Thinner tag construction i.e. foil antenna

Limitations on use of ferrite antennae e.g. higher cost

Penetrates wood/tissue

For animal applications, a more rigid construction is needed compared to usual plastic foil inlays to withstand the very tough environmental condition. This will increase the cost of the final Tag.









Ultra High Frequency 868 - 956 MHz

ADVANTAGES

DISADVANTAGES

High data rate: Can read up to 1500 tags per second (dependent on regional regulations)

Does not penetrate or transmit around metals The performance is badly affected by tissue, water absorption

= Not suitable for implants and Bolus

Thinner tag construction i.e. foil antenna

Sensitive to nearly any material around Reflexions may disturb the application

Lower manufacture cost for inlay only (secondary packaging of inlay most likely required for livestock tag)

Different performance worldwide due to local regulations

Large read range with line-of-sight communication (up to 8 meters)

Complex readers and antennas and set up required for gate applications

Penetrates wood

For animal applications, a more rigid construction is needed compared to usual plastic foil inlays to withstand the very tough environmental condition. This will increase the cost of the final Tag

For same performance compared to LF, larger tag size is required (<1m, button tag)









Frequency Selection

Parameter	Capability of Frequency Options		
	< 135 kHz	13.56 MHz	2.45 GHz/UHF
Cost Transponder Chip Antenna Reader	medium/low medium medium low	low lowest lowest medium	medium/low lowest lowest high
Range <i>Passive</i>	high	medium	medium /high
Form Factor flexibility	high	low	medium
Data Rate Down-Link (Reader to Transp.) UP-Link (Transp. to reader)	low low	medium medium	high high
Cost of Reader /Antennas	low	medium	high
Complexity (set up)	low	medium	high
Environment / Noise (EMI / B <i>roadband</i> Discrete <i>- in Band)</i>	Medium	Low	Medium
Environment, - Tissue/Human Body - Metal	NO absorption controllable	Lim. absorption controllable	Strong absorption reflection







